


AM2: QDG-FET Based SRAM


Revised

Cavin Farley
Kiran Nadkarni
Benas Kirvelevicius



Motivation

- Importance of looking at QDG-FETs
- Fundamental Benefits & Changes
- Applications
- Relevance in Constant Field Scaling




Background


- Additional States in Transfer Characteristic
- What is a Quantum Dot?
- Ability to have > 2 Logic States
- Conventional CMOS SRAM

Transistor Structure


- Standard MOSFET (a)
- QDG-FET (b)
 - This and the standard MOSFET are the types of FET we will be working with.
 - The channel is the same as (b) but with 4 layers of QDs instead of the two displayed here.
- QDG/QDC-FET (c)
- Our concern is the QDG-FET



(a) Adapted from [3]




(b) Adapted from [3]



(c) Adapted from [3]

Theory

- Similarities to MOSFET Design Theory
 - Relation between Leakage Current and Threshold Voltage
 - Desire to Minimize Leakage Current and Maximize "ON" Current
- Significant Differences to MOSFET Design
 - Changes in Governing Equations
 - Changes in the characteristic of the FET



Adapted from [1]

$$V_{TH-EFF} = V_{TH} + \Delta V_{TH}$$

$$\Delta V_{TH} = \begin{cases} 0, V_{GS} \leq V_{g1}, \text{State OFF} \\ \alpha 1(V_{GS} + V_{g1}), V_{g1} < V_{GS} \leq V_{g2}, \text{State i} \\ 1(V_{g2} + V_{g1}), V_{GS} > V_{g2}, \text{State ON} \end{cases}$$

$$I_{DS} = \left(\frac{W}{L}\right) C_{OX} \mu_n \left((V_{GS} - V_{TH-EFF}) V_{DS} - \frac{V_{DS}^2}{2} \right) \Delta V_{TH} = \begin{cases} 0, V_{GS} \leq V_{g1}, \text{OFF} \\ \alpha 1(V_{GS} + V_{g1}), V_{g1} < V_{GS} \leq V_{g2}, \text{MOD1} \\ \alpha 1(V_{g2} + V_{g1}), V_{g2} < V_{GS} \leq V_{g3} \\ \alpha 1(V_{g2} + V_{g1}) + \alpha 2(V_{GS} + V_{g3}), V_{g3} < V_{GS} \leq V_{g4}, \text{MOD2} \\ \alpha 1(V_{g2} + V_{g1}) + \alpha 2(V_{g4} + V_{g3}), V_{GS} \geq V_{g4}, \text{ON} \end{cases}$$

Adapted from [1]

Adapted from [1]

Theoretical basis

- Drain Current Calculations for a MOSFET
 - Simply uses a threshold voltage instead of an effective threshold voltage for different states.
- Resulting Characteristic Plots for a normal MOSFET
 - Lack of intermediate states and a smooth curve is formed. Not pictured is a point of saturation past the point of $V_g = 3V$.

$$I_{DS} = \left(\frac{W}{L}\right) C_{OX} \mu_n \left((V_{GS} - V_{TH}) V_{DS} - \frac{V_{DS}^2}{2} \right)$$

Adapted from [1]




Figure 1: MOSFET Designed in TCAD Sentaurus

Truth Table Structure Comparison

- Additional Bit is possible because $1/3V_{DD}$ and $2/3V_{DD}$ represent additional logic states due to four layers of Quantum Dots present (two rows for each state).

Table 2. CMOS 1 bit SRAM truth table.

Write signal	Data signal	Stored Data
0	0	Same State
0	1	Same State
1	0	0
1	1	1

Adapted from [1]


Table 4. The truth table of 2 bit SRAM.

Write signal	Data signal	Stored Data
0	0 V = Logic 0 (00)	Same State
0	$\frac{1}{3} V_{DD}$ = Logic 1 (01)	Same State
0	$\frac{2}{3} V_{DD}$ = Logic 2 (10)	Same State
0	V_{DD} = Logic 3 (11)	Same State
1	Logic 0 (00)	$> \frac{1}{6} V_{DD}$ = Logic 0 (00)
1	Logic 1 (01)	$\frac{1}{3} V_{DD}$ = Logic 1 (01)
1	Logic 2 (10)	$\frac{2}{3} V_{DD}$ = Logic 2 (10)
1	Logic 3 (11)	V_{DD} = Logic 3 (11)

Adapted from [1]



Energy Band Diagram

<u>Material</u>	<u>Band Gap</u>	<u>Thickness</u>
QD Si Core	1.1 eV	2nm
QD Si-Ox Cladding Layer	8.9 eV	1nm
Si-O ₂ Oxide Layer	9 eV	2nm
P-Type Silicon Substrate	1.1 eV	~140nm



SRAM Structure and Information

- Two cross-coupled and two single FETs (access transistors)
- The Word Line of the SRAM cell allows the auxiliary transistors to access the Bit Lines
- Bit Lines are what transports information regarding the Read/Write of the Cell
- Data is deposited into the cross-coupled Inverters
- Adding Transistors can separate the transistors used for read/write process.
- Adding QD Transistors with the proper software can allow for additional bits to be read/write without needing additional hardware.
- This is relevant because additional hardware density would not be necessary to accomplish the same speed increase per clock cycle.



General Processing Overview

1. Cleaning/Wet Oxidation for $\sim 1500\text{\AA}$
2. Source Drain Diffusion Mask
3. Gate Mask, Oxidation, Etching, Si QD Deposition w/ Annealing
4. Source - Drain Contacts & SiO₂ Removal with BOE
5. Al Contact & Interconnect Application


Processing: Wafer Cleaning and Wet-Oxidation

Cleaning Wafer

- On Hot Plate at 115°C
- Place Wafer in TCE - 2-5 min
- Place in Acetone - 2-5 min
- Place in Methanol - 2-5 min
- Rinse in Deionized Water
- Place in a 5% HF solution
- Rinse in Deionized Water
- Place in Piranha Solution ($1\text{H}_2\text{SO}_4 : 1\text{H}_2\text{O}_2$) - 5 min
- Rinse in Deionized Water
- Place in Boiling Propanol - 5 min

Wet-Oxidation (1400 Å)

- Place clean wafer inside the wet-oxidation furnace
- 2 min at the mouth - 500°C ~ 700°C
- 10 min inside furnace - 1000°C
- 2 min at the mouth - 500°C ~ 700°C



Processing: Drain and Source Masks 1

Applying Photoresist

On Hot Plate at 115°C

Place wafer and mounting wafer in TCE - 2-5 min

Place both wafers in Acetone - 2-5 min

Place both wafers in Methanol - 2-5 min

Rinse both wafers in Deionized Water

Blow both wafers dry with N₂

Bake both wafers at 115°C on hot plate for 3 min

Cool both wafers for 1 min

Mount the mounting wafer on the spinner using vacuum pressure

Apply S1813 Photoresist on mounting wafer then (Spin at 1000 RPM for 10 sec)

Place the wafer on the surface of the mounting wafer push sides of wafer to mount the wafer on the surface of the mounting wafer using the adhesion of the photoresist

Bake at 115°C for 10-12 min


Cool for 6 min under funnel

Blow dry with N₂

Apply Photoresist on wafer (Spin at 5000 RPM for 30 sec) creates ~1.2µm of photoresist layer

Bake at 115°C for 2 min

Cool for 2 min



Processing: Drain and Source Masks 2

UV Exposure

Mount the Drain & Source Opening mask in the mask aligner in such a way that the chromium side will be in contact with the wafer using vacuum pressure

Mount the mounting wafer and the sample at the center of the circular holding using vacuum pressure

Press the cycle button to see the microscopic view

Align the mask and the sample for UV exposure

Press cycle again to shine UV upon the sample for 30 sec.

Bake the sample for 1 minute

Cool the wafer for 1 minute

Developer

Prepare 351 developer solution with (1 developer : 3.5 H₂O)

Dip the sample in the DI water

Then immerse the wafer in the Developer solution for 12 seconds, while moving the wafer gently while in the solution

Rinse in DI water


Blow dry wafer with N₂

Post-bake for 10 minutes

Cool the sample for 2 minutes

Check the sample under microscope after developing for verification

(Avoid white light when the sample has photoresist and over exposing and developing)



Processing: Drain and Source Masks 3

Etching using Buffered Oxide Etch

Rinse sample in DI water

(Place wafer in BOE solution for 12 seconds (etch rate of 10\AA per second) to etch the oxide for total of 120\AA)

Rinse with DI water and blow dry with N_2

Check sample under microscope in order to verify etching

Removal of mounting wafer and photoresist

Rinse wafer and mounting wafer with acetone

Place both in acetone beaker at 135°C

Separate wafer and mounting wafer then blow dry mounting wafer with N_2

Immerse wafer in three separate hot acetone beakers at 135°C for 10 minutes each

Immerse sample in propanal


Diffusion

Place in furnace with a wafer of Phosphorus

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$

15 min inside furnace - 1000°C

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$



Processing: Gate Mask & Oxidation 1

Applying Photoresist

On Hot Plate at 115°C

Place wafer and mounting wafer in TCE - 2-5 min

Place both wafers in Acetone - 2-5 min

Place both wafers in Methanol - 2-5 min

Rinse both wafers in Deionized Water

Blow both wafers dry with N₂

Bake both wafers at 115°C on hot plate for 3 min

Cool both wafers for 1 min

Mount the mounting wafer on the spinner using vacuum pressure

Apply S1813 Photoresist on mounting wafer then (Spin at 1000 RPM for 10 sec)

Place the wafer on the surface of the mounting wafer push sides of wafer to mount the wafer on the surface of the mounting wafer using the adhesion of the photoresist

Bake at 115°C for 10-12 min


Cool for 6 min under funnel

Blow dry with N₂

Apply Photoresist on wafer (Spin at 5000 RPM for 30 sec) creates ~1.2µm of photoresist layer

Bake at 115°C for 2 min

Cool for 2 min



Processing: Gate Mask & Oxidation 2

UV Exposure

Mount the open gate mask in the mask aligner in such a way that the chromium side will be in contact with the wafer using vacuum pressure (This opens all the gates)

Mount the mounting wafer and the sample at the center of the circular holding using vacuum pressure


Press the cycle button to see the microscopic view

Align the mask and the sample for UV exposure

Press cycle again to shine UV upon the sample for 30 sec.

Bake the sample for 1 minute

Cool the wafer for 1 minute



Developer

Prepare 351 developer solution with (1 developer : 3.5 H₂O)

Dip the sample in the DI water

Then immerse the wafer in the Developer solution for 12 seconds, while moving the wafer gently while in the solution

Rinse in DI water

Blow dry wafer with N₂

Post-bake for 10 minutes

Cool the sample for 2 minutes

Check the sample under microscope after developing for verification

(Avoid white light when the sample has photoresist and over exposing and developing)

Processing: Gate Mask & Oxidation 3

Etching using Buffered Oxide Etch

Rinse sample in DI water

(Place wafer in BOE solution for 12 seconds (etch rate of 10\AA per second) to etch the oxide for total of 120\AA)

Rinse with DI water and blow dry with N_2

Check sample under microscope in order to verify etching

Removal of mounting wafer and photoresist

Rinse wafer and mounting wafer with acetone

Place both in acetone beaker at 135°C

Separate wafer and mounting wafer then blow dry mounting wafer with N_2

Immerse wafer in three separate hot acetone beakers at 135°C for 10 minutes each

Immerse sample in propanal


Dry-Oxidation (250\AA)

Place clean wafer inside the wet-oxidation furnace

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$

2 min 9 seconds inside furnace - 1000°C

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$



Processing: Gate Mask & Oxidation 4

Applying Photoresist

On Hot Plate at 115°C

Place wafer and mounting wafer in TCE - 2-5 min

Place both wafers in Acetone - 2-5 min

Place both wafers in Methanol - 2-5 min

Rinse both wafers in Deionized Water

Blow both wafers dry with N₂

Bake both wafers at 115°C on hot plate for 3 min

Cool both wafers for 1 min

Mount the mounting wafer on the spinner using vacuum pressure

Apply S1813 Photoresist on mounting wafer then (Spin at 1000 RPM for 10 sec)

Place the wafer on the surface of the mounting wafer push sides of wafer to mount the wafer on the surface of the mounting wafer using the adhesion of the photoresist

Bake at 115°C for 10-12 min


Cool for 6 min under funnel

Blow dry with N₂

Apply Photoresist on wafer (Spin at 5000 RPM for 30 sec) creates ~1.2µm of photoresist layer

Bake at 115°C for 2 min

Cool for 2 min



Processing: Gate Mask & Oxidation 5

UV Exposure

Mount the second gate mask in the mask aligner in such a way that the chromium side will be in contact with the wafer using vacuum pressure (opens select gates for Quantum dots)

Mount the mounting wafer and the sample at the center of the circular holding using vacuum pressure


Press the cycle button to see the microscopic view

Align the mask and the sample for UV exposure

Press cycle again to shine UV upon the sample for 30 sec.

Bake the sample for 1 minute

Cool the wafer for 1 minute



Developer

Prepare 351 developer solution with (1 developer : 3.5 H₂O)

Dip the sample in the DI water

Then immerse the wafer in the Developer solution for 12 seconds, while moving the wafer gently while in the solution

Rinse in DI water

Blow dry wafer with N₂

Post-bake for 10 minutes

Cool the sample for 2 minutes

Check the sample under microscope after developing for verification

(Avoid white light when the sample has photoresist and over exposing and developing)

Processing: Gate Mask & Oxidation 6

Etching using Buffered Oxide Etch

Rinse sample in DI water

(Place wafer in BOE solution for 20 seconds (etch rate of 10\AA per second) to etch the oxide for total of 200\AA)

Rinse with DI water and blow dry with N_2

Check sample under microscope in order to verify etching

Removal of mounting wafer and photoresist


Rinse wafer and mounting wafer with acetone

Place both in acetone beaker at 135°C

Separate wafer and mounting wafer then blow dry mounting wafer with N_2

Immerse wafer in three separate hot acetone beakers at 135°C for 10 minutes each

Immerse sample in propanal




Dry-Oxidation (20\AA)

Place clean wafer inside the wet-oxidation furnace

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$

9 seconds inside furnace - 1000°C

2 min at the mouth - $500^\circ\text{C} \sim 700^\circ\text{C}$



Processing: Quantum Dots 1

Processing/annealing QD

Place silicon or germanium powder in a jar with nickel balls

Place jar in glove box and purge box of oxygen

Place jar in the miller

Run the miller for 99 mins, 99 sec three times

Place jar in glove box and purge box of oxygen

Empty the jar, scrape particulate off the sides and place the particulate in a glass vial

Mix the ethanol and benzoyl peroxide into the glass vial (grows oxide and reduces dot size)

Place glass vial into the sonicator and shake the solution

Place vial into centrifuge and run at 4 speeds (3k, 6k, 9k, and 13k RPM) for 30 minutes each (will separate into a black solution and clear solution)

Remove the clear solution and put into a new glass vial


Add a solution of HF, ethanol, and benzoyl peroxide to the glass vial.

Put solution in a glass petri dish and submerge the wafer in the solution

2 min at the mouth

Anneal QD in 800°C oxygen for 5 minutes

2 min at the mouth



Processing: Quantum Dots 2

Processing/annealing QD

Place silicon or germanium powder in a jar with nickel balls

Place jar in glove box and purge box of oxygen

Place jar in the miller

Run the miller for 99 mins, 99 sec three times

Place jar in glove box and purge box of oxygen

Empty the jar, scrape particulate off the sides and place the particulate in a glass vial

Mix the ethanol and benzoyl peroxide into the glass vial (grows oxide and reduces dot size)

Place glass vial into the sonicator and shake the solution

Place vial into centrifuge and run at 4 speeds (3k, 6k, 9k, and 13k RPM) for 30 minutes each (will separate into a black solution and clear solution)

Remove the clear solution and put into a new glass vial


Add a solution of HF, ethanol, and benzoyl peroxide to the glass vial.

Put solution in a glass petri dish and submerge the wafer in the solution

2 min at the mouth

Anneal QD in 300°C argon for 5 minutes

2 min at the mouth



Processing: Source & Drain Contact Mask 1


Dry-Oxidation (20 Å)

Place clean wafer inside the wet-oxidation furnace

2 min at the mouth - 500°C ~ 700°C

9 seconds inside furnace - 1000° C


2 min at the mouth - 500°C ~ 700°C



Processing: Source & Drain Contact Mask 2

Applying Photoresist

- On Hot Plate at 115°C
- Place wafer and mounting wafer in TCE - 2-5 min
- Place both wafers in Acetone - 2-5 min
- Place both wafers in Methanol - 2-5 min
- Rinse both wafers in Deionized Water
- Blow both wafers dry with N₂
- Bake both wafers at 115°C on hot plate for 3 min
- Cool both wafers for 1 min
- Mount the mounting wafer on the spinner using vacuum pressure
- Apply S1813 Photoresist on mounting wafer then (Spin at 1000 RPM for 10 sec)
- Place the wafer on the surface of the mounting wafer push sides of wafer to mount the wafer on the surface of the mounting wafer using the adhesion of the photoresist
- Bake at 115°C for 10-12 min
- Cool for 6 min under funnel
- Blow dry with N₂
- Apply Photoresist on wafer (Spin at 5000 RPM for 30 sec) creates ~1.2µm of photoresist layer
- Bake at 115°C for 2 min
- Cool for 2 min



Processing: Source & Drain Contact Mask 3

UV Exposure

Mount the Open source and drain contacts mask in the mask aligner in such a way that the chromium side will be in contact with the wafer using vacuum pressure

Mount the mounting wafer and the sample at the center of the circular holding using vacuum pressure


Press the cycle button to see the microscopic view

Align the mask and the sample for UV exposure

Press cycle again to shine UV upon the sample for 30 sec.

Bake the sample for 1 minute

Cool the wafer for 1 minute



Developer

Prepare 351 developer solution with (1 developer : 3.5 H₂O)

Dip the sample in the DI water

Then immerse the wafer in the Developer solution for 12 seconds, while moving the wafer gently while in the solution

Rinse in DI water

Blow dry wafer with N₂

Post-bake for 10 minutes

Cool the sample for 2 minutes

Check the sample under microscope after developing for verification

(Avoid white light when the sample has photoresist and over exposing and developing)

Processing: Source & Drain Contact Mask 4

Etching using Buffered Oxide Etch

Rinse sample in DI water

(Place wafer in BOE solution for 29 seconds (etch rate of 10\AA per second) to etch the oxide for total of 290\AA)

Rinse with DI water and blow dry with N_2

Check sample under microscope in order to verify etching

Removal of mounting wafer and photoresist


Rinse wafer and mounting wafer with acetone

Place both in acetone beaker at 135°C

Separate wafer and mounting wafer then blow dry mounting wafer with N_2

Immerse wafer in three separate hot acetone beakers at 135°C for 10 minutes each

Immerse sample in propanal



Processing: Al Metallization & Interconnect Mask 1

Metalize device

Place wafer in Aluminum evaporation machine for 9 minutes and 30 seconds in order to add 1500Å of aluminum

Applying Photoresist

On Hot Plate at 115°C

Place wafer and mounting wafer in TCE - 2-5 min

Place both wafers in Acetone - 2-5 min

Place both wafers in Methanol - 2-5 min

Rinse both wafers in Deionized Water

Blow both wafers dry with N₂

Bake both wafers at 115°C on hot plate for 3 min

Cool both wafers for 1 min

Mount the mounting wafer on the spinner using vacuum pressure

Apply S1813 Photoresist on mounting wafer then (Spin at 1000 RPM for 10 sec)

Place the wafer on the surface of the mounting wafer push sides of wafer to mount the wafer on the surface of the mounting wafer using the adhesion of the photoresist

Bake at 115°C for 10-12 min


Cool for 6 min under funnel

Blow dry with N₂

Apply Photoresist on wafer (Spin at 5000 RPM for 30 sec) creates ~1.2µm of photoresist layer

Bake at 115°C for 2 min

Cool for 2 min



Processing: Al Metallization & Interconnect Mask 2

UV Exposure

Mount the Patterns for interconnects mask in the mask aligner in such a way that the chromium side will be in contact with the wafer using vacuum pressure

Mount the mounting wafer and the sample at the center of the circular holding using vacuum pressure


Press the cycle button to see the microscopic view

Align the mask and the sample for UV exposure

Press cycle again to shine UV upon the sample for 30 sec.

Bake the sample for 1 minute

Cool the wafer for 1 minute



Developer

Prepare 351 developer solution with (1 developer : 3.5 H₂O)

Dip the sample in the DI water

Then immerse the wafer in the Developer solution for 12 seconds, while moving the wafer gently while in the solution

Rinse in DI water

Blow dry wafer with N₂

Post-bake for 10 minutes

Cool the sample for 2 minutes

Check the sample under microscope after developing for verification

(Avoid white light when the sample has photoresist and over exposing and developing)

Processing: Al Metallization & Interconnect Mask 3

Etch Aluminum

Rinse sample in DI water

(Place wafer in Aluminum solution for 2 minutes and 6 seconds or until all aluminum not covered is removed)

Rinse with DI water and blow dry with N₂

Check sample under microscope in order to verify etching

Removal of mounting wafer and photoresist


Rinse wafer and mounting wafer with acetone

Place both in acetone beaker at 135°C

Separate wafer and mounting wafer then blow dry mounting wafer with N₂


Immerse wafer in three separate hot acetone beakers at 135°C for 10 minutes each

Immerse sample in propanal



Id-Vg Plot Characteristics

- The characteristic is fairly accurate to the predicted result, with deviations mostly due to noise.
- The effect of the additional voltage states are seen in both the predicted and experimental characteristics as the multiple states due to the presence of QDs is visible.
- QDs do this because as they are insulated semiconductor material, charge carriers tunnel as a further gate voltage is applied, but only at a significant point, causing the intermediate states.
- Important to note that intermediate states are mainly the plateaus in the characteristic, not the significant positive slope.



(a)



(b)



Id vs. V_g Characteristics

(a) Experimental Curve

(b) Theoretical Curve

Vin vs Vout Plot Characteristics

- The two intermediate states can also be seen in this characteristic as well.
- Reminiscent of the transfer characteristics of a CMOS inverter, as the NMOS transistor would start off conducting while the PMOS is cutoff and as the input current increases the NMOS eventually becomes cutoff as the PMOS transistor conducts, allowing for an inversion curve.
- Process is changed slightly through the presence of QDs.
- The trend of the inversion can only continue once the previously referenced Gate Voltage requirement for the QDs has been surpassed.



(a) Vin vs. Vout Characteristics

(b)

(a) Experimental Curve

(b) Theoretical Curve

Conclusion & Future Work

- Moore's Law nearing the atomic limit
 - Si atoms have ~ 0.2 nm diameter, meaning even advanced GAA-FETs will eventually hit a limit the same way Planar FETs and FinFETs have. Adding additional Logic Bits tackles the problem a different way!
- Benefit of logic beyond Binary
 - More information communicated leading to less interconnections necessary.
 - Higher amount of information leading to less dense circuits necessary.
 - Information communicated faster per clock cycle leading to faster processing.
 - A less dense circuit requires less fabrication steps and processing precision which also brings economic benefits.

References

- [1] B. Saman, J. Kondo, J. Chandy, and F. C. Jain, "Circuits and Simulation of Quaternary SRAM Using Quantum Dot Channel Field Effect Transistors (QDC-FETs)," *International Journal of High Speed Electronics and Systems*, vol. 27, no. 01n02, p. 1840004, 2018.
- [2] F. Hetsch, N. Zhao, S. V. Kershaw, and A. L. Rogach, "Quantum dot field effect transistors," *Materials Today*, vol. 16, no. 9, pp. 312–325, 2013.
- [3] S. Karmakar, J.A. Chandy, M. Gogna, and F.C. Jain, Fabrication and Circuit Modeling of NMOS Inverter Based on Quantum Dot Gate Field-Effect Transistors, *Journal of ELECTRONIC MATERIALS*, Vol. 41, No. 8, 2012
- [4] J. A. Elias, "Class 16: Memories," in *UK College of engineering*.
- [5] Butterfield, Nathan, "Fabrication, Testing and Theoretical Background of a Quantum Dot Floating Gate Flash Non-Volatile Memory (QDG NVM)" (2020). Master's Theses. 1530.
- [6] S. Karmakar and F. C. Jain, "Ternary static random access memory using quantum dot gate field-effect transistor," *Micro & Nano Letters*, vol. 10, no. 11, pp. 621–624, 2015.